

# Simplified Target

Based on minimum pcf requirement as shown.

## (>434 psf Bond Strength at a target dry density of **15.5** pcf) Yield: **43.7 BF/BAG (4.06 m2)**

|                  | TARGET | RANGE       | UNIT    |
|------------------|--------|-------------|---------|
| ACCELERATOR A-20 | 1260   | 1250 – 1270 | g/l     |
| WATER            | 8.5    | 8.0 - 9.0   | gal/bag |
| NOZZLE DENSITY   | 533    | 514 – 551   | g/l     |
|                  |        |             |         |

#### (>1,000 psf Bond Strength at a target dry density of **16.5** pcf) Yield: **41.0 BF/BAG (3.81 m2)**

|                  | TARGET | RANGE       | UNIT    |
|------------------|--------|-------------|---------|
| ACCELERATOR A-20 | 1260   | 1250 – 1270 | g/l     |
| WATER            | 8.5    | 8.0 - 9.0   | gal/bag |
| NOZZLE DENSITY   | 567    | 547 - 586   | g/l     |
|                  |        |             | -       |

## (>3000 psf Bond Strength at a target dry density of 22 pcf) Yield: 30.8 BF/BAG (2.86 m2)

|                  | TARGET | RANGE       | UNIT    |
|------------------|--------|-------------|---------|
| ACCELERATOR A-20 | 1200   | 1190 - 1210 | g/l     |
| WATER            | 8.5    | 8.0 – 9.0   | gal/bag |
| NOZZLE DENSITY   | 756    | 730 - 782   | g/l     |

**HOLD POINT:** Yields measured in excess of 45.1 BF/Bag will result in dry densities below the minimum 15 PCF as published in the Underwriters Laboratories Inc.® Fire Resistance Directory.

Simplified Range (Carboline recommends nozzle yields be taken a minimum, 3 times per day. Carboline recommends the use of a 9/16 I.D orifice)

|      | Viol | d (*) |    | 8.0 | US/G            | 8.5 | US/G | 9.0 | US/G | 9.5  | US/G | 10.0 | US/G | Dry<br>Density<br>(PCF) |  |
|------|------|-------|----|-----|-----------------|-----|------|-----|------|------|------|------|------|-------------------------|--|
|      | riei | u()   |    | 30  | L               | 32  | L    | 34  | L    | 36   | L    | 38   | L    |                         |  |
| 2.86 | m²   | 30.8  | BF | 7:  | 30              | 756 |      | 78  | 32   | 80   | 08   | 834  |      | 22                      |  |
| 3.49 | m²   | 37.6  | BF | 59  | 597 618 640 661 |     | 61   | 68  | 32   | 18.0 |      |      |      |                         |  |
| 3.81 | m²   | 41.0  | BF | 54  | 47              | 56  | 67   | 58  | 36   | 60   | 06   | 62   | 26   | 16.5                    |  |
| 4.06 | m²   | 43.7  | BF | 5   | 14              | 53  | 33   | 5   | 51   | 56   | 69   | 58   | 38   | 15.5                    |  |
|      | I.   |       |    | 1   |                 | 1   |      | 1   |      | 1    |      |      |      |                         |  |

(\*) Yield based on 1-inch (25.4mm) thickness. All weights shown are measured in grams. Cup weights are based on an actual 1000ml (11) cup as supplied by Carboline (contact your local Carboline Fireproofing representative for cups).

Non-Carboline alternate cups can be purchased from major home improvement suppliers, these cups average 1038 ml when filled to the top. If utilizing these cups, multiply the cup weight by an average of 1.038 to provide accurate density/yield values.



# SOUTHWEST TYPE 5MD™

SIMPLIFIED YIELD CHART – INJECTED

#### **Supplementary Information**

#### Accelerator A-20 Mixing

(**15.5- 16.5 PCF:** mix four 50 lb Bag/34 Gallons Water (total solution equals 44 gallons) (**22 PCF:** mix three 50 lb Bag/37.5 Gallons Water (total solution equals 45 gallons)

- 1. Mix accelerator A-20 as directed on the product data sheet. Allow bubbles in the solution to pop before checking density.
- 2. Use a 1-liter plastic container, place on scale and zero/tare container.
- 3. Fill the container level to the top with A-20 solution.
- 4. If weight is below 1265 g/l, add additional A-20 to mix until target is reached.
- 5. As an alternate to 1-3 above, place a hydrometer in the solution and determine the specific gravity.

|         | Accelerator A-20 Flow Rate (15 pcf) |                    |  |  |  |  |  |  |  |
|---------|-------------------------------------|--------------------|--|--|--|--|--|--|--|
| Bags/HR | Seconds to fill 1-liter             | Alum. Pump Setting |  |  |  |  |  |  |  |
|         | cup                                 | (%)                |  |  |  |  |  |  |  |
| 5       | 318                                 | 5                  |  |  |  |  |  |  |  |
| 10      | 129                                 | 14                 |  |  |  |  |  |  |  |
| 15      | 84                                  | 24                 |  |  |  |  |  |  |  |
| 20      | 63                                  | 33                 |  |  |  |  |  |  |  |
| 25      | 51                                  | 43                 |  |  |  |  |  |  |  |
| 30      | 43                                  | 52                 |  |  |  |  |  |  |  |
|         |                                     |                    |  |  |  |  |  |  |  |

|   |         | Accelerator A-20 F      | low Rate (16.5 pcf) |
|---|---------|-------------------------|---------------------|
| ÷ | Bags/HR | Seconds to fill 1-liter | Alum. Pump Setting  |
|   |         | cup                     | (%)                 |
|   | 5       | 1637                    | 1                   |
|   | 10      | 278                     | 6                   |
|   | 15      | 163                     | 11                  |
|   | 20      | 117                     | 16                  |
|   | 25      | 93                      | 21                  |
|   | 30      | 77                      | 27                  |

#### Nozzle Density

- 1. Set the A-20 solution flow rate to a quick dribble.
- 2. Commence spraying and pump for roughly 60 seconds until the system stabilizes.
- 3. After 60 seconds, spray TYPE 5MD directly into the Carboline 1000ml cup. Position the nozzle 12-18" above the cup and overfill.
- 4. Strike off any excess TYPE 5MD and level to the top of the container. Wait a further 60 seconds or until such time the material has stopped swelling. Again, strike level with the top of the container.
- 5. Place an empty container on the scale and press "on/tare"
- Replace the tared container with the identical container, filled with TYPE 5MD and record the net weight.
- Cross reference the above chart to determine yield and adjust injection flow rate as required based on bond strength requirements. A minimum density of 16.5 pcf is required to meet 1,000 psf bond strength.

#### Calculation

To calculate yield, follow the formula noted below:

Yield = 12 x (Gallons H<sup>2</sup>o/Bag x 8.34 + Bag Weight)/Nozzle Density

To convert g/L to pcf for Nozzle Density, follow the formula below:

g/L x 0.06243



## Simplified Target

Based on minimum 22 pcf. Requirement

|                | TARGET | RANGE     | UNIT    |  |  |  |  |  |  |  |
|----------------|--------|-----------|---------|--|--|--|--|--|--|--|
| WATER          | 8.5    | 8.0 - 9.0 | gal/bag |  |  |  |  |  |  |  |
| NOZZLE DENSITY | 741    | 716 - 767 | g/l     |  |  |  |  |  |  |  |

Vield: 31 4 BE/BAG (2 91 m2)

Simplified Range (Carboline recommends nozzle yields be taken a minimum, 3 times per day. Carboline recommends the use of a 9/16 I.D orifice)

|      | Vial | d (*) |    | 8.0 | US/G | 8.5 | US/G | 9.0 | US/G | 9.5  | US/G | 10.0 | US/G |                  |
|------|------|-------|----|-----|------|-----|------|-----|------|------|------|------|------|------------------|
|      | rier | u()   |    | 30  | L    | 32  | L    | 34  | L    | 36   | L    | 38   | L    | Density<br>(PCF) |
| 2.29 | m²   | 24.6  | BF | 9   | 911  |     | 14   | 9   | 76   | 1009 |      | 1041 |      | 28.0             |
| 2.47 | m²   | 26.5  | BF | 846 |      | 87  | 76   | 90  | 06   | 93   | 37   | 96   | 67   | 26.0             |
| 2.67 | m²   | 28.8  | BF | 781 |      | 80  | 09   | 8   | 37   | 80   | 65   | 89   | 93   | 24.0             |
| 2.91 | m²   | 31.4  | BF | 716 |      | 74  | 41   | 70  | 67   | 79   | 93   | 8    | 18   | 22.0             |

(\*) Yield based on 1-inch (25.4mm) thickness. All weights shown are measured in grams. Cup weights are based on an actual 1000ml (11) cup as supplied by Carboline (contact your local Carboline Fireproofing representative for cups).

Non-Carboline alternate cups can be purchased from major home improvement suppliers, these cups average 1038 ml when filled to the top. If utilizing these cups, multiply the cup weight by an average of 1.038 to provide accurate density/yield values.

# **Supplementary Information**

## Nozzle Density

- 1. Spray un-injected TYPE 5MD directly into the Carboline 1000ml cup. Position the nozzle 12-18" above the cup and overfill.
- 2. Strike off any excess TYPE 5MD and level to the top of the container.
- 3. Place an empty container on the scale and press "on/tare"
- 4. Replace the tared container with the identical container, filled with TYPE 5MD and record the net weight.
- 5. Cross reference the above simplified range to determine yield and adjust water, mixing time and/or air pressure accordingly.

## Calculation

To calculate yield, follow the formula noted below:

Yield = 12 x (Gallons H<sup>2</sup>o/Bag x 8.34 + Bag Weight)/Nozzle Density

To convert g/L to pcf for Nozzle Density, follow the formula below:

g/L x 0.06243