



Intumescent Fireproofing Approved Primer List

October 2024

Primer (see footnote)	VOC (g/l)	A/D Firefilm III	A/D Firefilm III C	Firefilm IV	Thermo-Sorb VOC	Thermo-Sorb 263	Thermo-Lag E100	Thermo-Lag E100 S	Thermo-Lag 3000	Pyroclad X1
Carbocoat 115	419	2	2							
Carbocoat 115 VOC	340	2	2	2	2	2				
Carbocoat 150 UP	409	2	2	2	2	2				
Carbocoat 112	340	2	2	2	2	2				
Carbocoat 116	249	2	2	2	2	2				
Carbocoat 8229	268	2	2	2	2	2	2	2	2	
Carbocoat 8239	335	2	2	2	2	2				
Sanitile 120	98	2,3	2,3	2,3	1,3					
Carbocrylic 3350	250	2,3	2,3	2,3						
Carbocrylic 3358	153	2	2	2	2	2				
Carbocrylic 3359 DTMC	44	1	1	1	1	1				
Carboguard 553	80	1	1	1			1	1	1	
Carboguard 635	296	1	1	1	1	1	1	1	1	1
Carboguard 635 VOC	246	1	1	1	1	1	1	1	1	
Carboguard 890	214						1	1	1	1
Carboguard 893 SG LT	318	1	1	1			1	1	1	
Carboguard 893 SG	336	1	1	1	1	1	1	1	1	1
Carboguard 60	240	1	1	1	1	1	1	1	1	1,5
Carboguard 8922	335	1	1	1	1	1	1	1	1	
Carbomastic 94	120	1	1	1	1	1	1	1	1	1,5
Carbomastic 94 MC	95	1	1	1	1	1	1	1	1	
Carbomastic 94 TL	95	1	1	1	1	1	1	1	1	
Carbomastic 15	88				1	1	1	1	1	
Carbomastic 242	327						1	1	1	
Carbomastic 615	172						1	1	1	1
Carbozinc 858	318						1,5	1,5	1,5	1,5
Carbozinc 859	326				1	1	1	1	1	
Carbozinc 859 VOC	95				1				1	
Rustbond	85	1,3,4	1,3,4	1,3,4	1,3,4	1,3,4	1,3,4	1,3,4	1,3,4	
Carbozinc 11 + Carboguard 893 SG	479 336						1	1	1	
Carbozinc 11 + Rustbond	479 85						1,4	1,4	1,4	
Carbozinc 11 HS + Carboguard 893	288 195									1,5

Footnote:

- (1) Designates primers that require a minimum 24 hr. cure @ 70°F before applying intumescent fireproofing.
- (2) Designates primers that require a minimum 7 day cure @ 70°F before applying intumescent fireproofing.
- (3) Designates primers that can only be used as tie-coat primers under intumescent fireproofing.
- (4) Contact Carboline Technical Service before applying Rustbond for exterior applications.
- (5) Designates primer that is NORSOK tested and compliant.